

VIZUALOGIC BLUETOOTH USER'S OPERATION GUIDE

ID: NSV-CIG Pin code: 1234

	Function	Operation	SPEC
	During initial use of this product, please enter the password"1234"from your cell phone to automatically connect with the control box.		
1	ACC on	Turn on Bluetooth	On ignition, if pairing has been done, the cell phone will automatically connect to the Bluetooth device. If pairing is not completed, then it will enter pairing mode. Each cell phone must first be paired with the device before using.
2	Pairing	Press button and hold 10 seconds.	Press button and hold 10 seconds. Then you can use phone to active the pairing. (Handsfree profile needs to complete the connection, whereas "Headset profile" does not).
3	Answer a call	Short press button	Short press button to pick up an incoming call.
4	Ending a call	Press button and hold 5 seconds	Press button and hold 5 seconds to end a call.
5	Rejecting a call	Press button and hold 2~5 seconds	Press button and hold 2~5 seconds to reject an incoming call.
6	Adjust the volume	Short press button	When the volume is adjusted up to MAX/MIN.
7	Transfer a call	Press button and hold 2 seconds	Press button and hold 2 seconds during a call. It will transfer the call. (Handsfree → Bluetooth cell phone / Bluetooth call phone → Handsfree)
8	Redialing the last number	Press button and hold 2 seconds	In standby mode, press button and hold 2 seconds will redial the last number.
9	Voice dialing	Short press button	In standby mode, short presses to start a voice dial control.
10	Memory erase	Press button and hold 15 seconds	Press button and hold 15 seconds to erase all pairing from the device. If memory is erased, and immediately enter pairing mode. In the pairing mode, the user needs to re-pair the cell phone with the device to use the Bluetooth function. Refer to "2. Pairing" above for more instructions. (Pin code : 1234)

* For others cell phone Bluetooth setting, please refer your cell phone's user manual.